

# LAKOS Visual Purge Kit

VP-07-HKV

## *Convenient see-through pipe helps identify when to purge a LAKOS Separator*


This assembly includes a durable manual valve and a length of clear plastic pipe with the proper fittings for installing directly onto the purge connection of a LAKOS Sand Separator.

Be sure to purge regularly in order to avoid compacted build-up of sand in the separator's collection chamber. Consult LAKOS for automatic purging options.

## *Installation*

Use teflon tape on all threaded connections. Attach the see-through pipe end of the Visual Purge Kit onto the purge outlet of the separator. The manual valve should be below the see-through pipe section.

Use caution when purging to avoid excessive torque on the see-through pipe and connection to the separator.



Lakos Separators are manufactured and sold under one or more of the following U.S. Patents: 3,289,608; 3,512,651; 3,568,837; 3,701,425; 3,947,364; 3,963,073; 4,027,481; 4,120,795; 4,123,800; 4,140,638; 4,147,630; 4,148,735; 4,305,825; 4,555,333; 5,320,747; 5,338,341; 5,368,735; 5,425,876; 5,571,416; 5,578,203; 5,622,545; 5,653,874; 5,894,995; 6,090,276; 6,143,175; 6,167,960; 6,202,543; Des. 327,693; and corresponding foreign patents; other U.S. and foreign patents pending.

# LAKOS®

1365 N. Clovis Avenue • Fresno, California 93727 USA  
Telephone: (559) 255-1601 • Fax: (559) 255-8093  
Toll-Free: (800) 344-7205 (USA, Canada & Mexico)  
www.lakos.com • E-mail: info@lakos.com